

INSTALLATION INSTRUCTIONS

Quick Top 2

FOR WORKSHOP USE ONLY

Attach the holder to the vehicle with ring washers (Ø 20 mm diameter) using the existing drill holes.

Notice:

The user is responsible on his own for the correct and professional installation. Especially detection angles of vehicle cameras and sensors must not be affected. Please ask us for alternatives in case of problems with limited space.

Illustration 1 - Insert the sign

Insert the sign (in direction of arrow 1) from the bottom up under the top lugs of the baseplate.

Tip: In case of curved mounting situations the fitting of the holder to the car can be optimised by pre-bending the plate itself.

Then press both buttons and push the bottom edge of the sign into the left and right holding clamp (in direction of arrow 2). The sign is held now.

Illustration 2 - Closing

Attention!

Push the sides (the right one is marked with an „R“) of the manually pre-curved advertising bar into the left and right holding fixture at the bottom of the baseplate (see arrow 1).

Then press the bar from the left and right side towards the middle into the baseplate, **so that it locks with hearable “click” sounds.**

The installation of the sign is completed.

Bild 3 a and 3 b - Deinstallation

Insert the opening tool (or a screwdriver) in the middle of the advertising bar between the sign and the bar, until the bar is unlocked and spread open. Then take the bar in the middle and pull it carefully out of the baseplate (in direction of arrow 2).

Press the buttons and remove the sign.



Illustration 1



Illustration 2

Opening tool
(detail)



Illustration 3 a



Illustration 3 b